

EXTT Series Torque Tester

Model	Torque Range (Nm)	Torque Range (in.-lb.)	Weight (kg)	Weight (lb)	Rundown Adapter	Adapter Service Kit
EXTT-1	0.1 - 1	0.88 - 8.8	2.1	4.5	ETT-RA-1	ETT-RA-1-KIT
EXTT-4	0.4 - 4	3.5 - 35	2.1	4.5	ETT-RA-4	ETT-RA-4-KIT
EXTT-12	1.2 - 12	10.6 - 106	2.1	4.5	ETT-RA-12	ETT-RA-12-KIT
EXTT-30	3.0 - 30	26.5 - 265	2.1	4.5	ETT-RA-30	ETT-RA-30-KIT

© 2015 Ingersoll Rand. All rights reserved.